

Some Other Popular Toys

Aqua Lamp #305

Ring around Bells #23

Dome Alone #69

Dome Alone with Switch #71

Drum #80

Musical Rolling Pin #160

Musical Light Box #200

Stacking Blocks #359

Stacking Ring Cone #360

Musical Top #400

Vibrating Light with Music #459

Glitter Roll #696

Motorized Glitter Roll #697

Butterfly Light and Music Puzzle #922

Traffic Light #1800

Hungry Hippo

Catalog # 737

User's Guide

Hungry Hippo

Our adapted game has 2 paddles attached to the Hippos for easy activation. Just simply bang away and watch as the Hippos race to gobble up as many marbles as possible. A great game to play with friends or family. Easy and tons of fun. Size: 24"L x 16"W x 3.5"H.

Operation:

1. The Hungry Hippo requires some assembly, please see original manufactures instructions.
2. After assembling the game place the game on a flat level surface. The game can be clamped in place with the use of a C-Clamp if needed.
3. Place 5 marbles in each user's marble tray. By pressing the marble release lever a marble will be released. As soon as the marble is released, all players try to make their Hippos gobble it up by pressing the Hippo tails or the adapted paddle pad until someone succeeds.
4. **Please note: only two of the Hippos have been adapted with the paddle pads.**

Troubleshooting:

Problem: The Paddle does not move the Hungry Hippo or the Hippo's head sticks.

Action: Check that no debris or small objects are blocking or obstruction any of the paddle, or the Hippo's head and neck.

Action #2: Put a drop of 3 and 1 oil or like oil on the spring located at the end of the Hippo's neck when it meets the Hippo's head...

Care of Unit:

The Hungry Hippo can be wiped clean with any household multi-purpose cleaner and disinfectant.

Do not use abrasive cleaners, as they will scratch the surface of the unit

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com

