SmartView Pocket

User Manual Guide d'utilisation

SmartView Pocket




This document will show you how to use your SmartView Pocket's many features.

- 1. Contents of the Package
- Handheld video magnifier
- Power supply
- USB cable
- RCA video cable
- Protective case
- Carrying strap
- Cleaning cloth
- User Guide
- Warranty Card

- 2. SmartView Pocket's features location
- 1: Power button
- 2: Reset button
- **3: Light button**
- 4: Freeze image button
- 5: Power light
- 6: Charge light
- 7: Increase (+) button
- 8: Decrease (-) button
- 9: Settings button
- 10: Mode button
- 11: USB port
- 12: A/V port



- 3. Using the SmartView Pocket
- 3.1 Positioning the SmartView Pocket's stand





3.2 Reading and writing positions





3.3 Key Description

Кеу	Function
Power	Used to power on/off.
Reset	Only use if the SmartView Pocket stops responding. Press Power to restart.
Light	Turn on/off light that illuminates viewing surface.
Freeze	Freeze an image.
Settings	Zoom / Brightness / Environment / Sound. Selected Setting can be modified with Increase (+) and Decrease (-) buttons. Setting will remain on current value until pressed again. Leave setting in Zoom for normal operation.
Mode	Image mode toggle: Color / Gray / Negative / Positive
Increase (+)	Used to change the selected setting.
Decrease (-)	Used to change the selected setting.

3.4 Recharging the Battery

To recharge the SmartView Pocket:

- Connect the power supply to one end of the USB cable.
- Connect the other end of the USB connector to the SmartView Pocket's USB port.
- Plug the power supply to an electrical outlet.

The SmartView Pocket needs to be plugged in for approximately 3 hours to reach full charge. The charger light will turn off when fully charged.

Once fully charged, the SmartView Pocket can be used for a period of about 3 hours.

3.5 Connecting to a TV screen

If you wish to view the magnified image on a larger screen, you can connect the SmartView Pocket to a television. To do so, plug the RCA video cable's single connector to the SmartView Pocket's A/V port located on the left edge. Plug the yellow (video) connector to video input port on your television. The remaining sound connectors are not used.

Warning: Avoid exposure to moisture, rain, sand and extreme temperatures