# St. Bernard Puppy #437

## **USER'S GUIDE**



#### Bow Wow!

Take your St. Bernard Puppy for a walk. He walks forward and backwards, and wags his tail while barking. He is a wonderful pet to have, so soft and cuddly. Size:  $8 \frac{1}{2}$  "L x  $4 \frac{1}{2}$  "W x 7"H. Requires 2 AA Batteries.

#### **Operation:**

- 1. St. Bernard Puppy requires 2 AA Batteries to operate. Alkaline batteries must be used (e.g. Duracell or Energizer Brands). Do not use rechargeable batteries because they supply a lower voltage and the unit may not perform as well. Never mix old and new batteries together or different brands or types together.
- 2. Turn St. Bernard Puppy upside down to reveal the battery compartment. Remove the small screw with a Phillips Head screwdriver. Install 2 AA batteries paying close attention to proper battery polarity. Replace the battery compartment cover and screw.
- 3. Connect St. Bernard Puppy to any external capability switch (not included) via the jack located at the end of St. Bernard Puppy's cord. St. Bernard Puppy is equipped with a 1/8" jack for use with external capability switches with a 1/8" plug. Make sure to make a tight connection. There should be no gaps.
- 4. Actuate your external capability switch and St. Bernard Puppy will spring to life! He walks forward, backwards, barks and wags his tail.
- 5. St. Bernard Puppy will remain on while the external capability switch continues to be actuated. Once you release the external capability switch St. Bernard Puppy will turn off.

### **Troubleshooting:**

**Problem:** St. Bernard Puppy does not function correctly.

**Action #1:** Replace the batteries paying close attention to proper (+) & (-) battery polarity.

**Action #2:** Make sure that the connection between the external capability switch and the jack is TIGHT. There should be NO gaps.

**Action #3:** Try your switch with another switch operated toy/device in an effort to rule out your switch as the source of the problems.

#### Care of Unit:

- Do not inhibit St. Bernard Puppy's movement, as this may cause irreversible damage.
- Do not lift St. Bernard Puppy up by his head, tail or legs, or drop St. Bernard Puppy.
- If you will not be using St. Bernard Puppy for an extended amount of time, we recommend removing the batteries.

**Do not submerge** the unit in water, as it will damage the electrical components. St. Bernard Puppy is surface washable only.