

drive
MEDICAL DESIGN & MANUFACTURING



3 POSITION *Recliner*

D577

IMPORTANT SAFETY GUIDELINES

PERIODICALLY INSPECT ALL PARTS AND REPLACE AS NEEDED • OCCUPANT WEIGHT SHOULD NOT EXCEED 250 LBS.
CASTER WHEELS SHOULD BE LOCKED DURING OCCUPANT TRANSFER

ASSEMBLY INSTRUCTIONS:

1. Remove back assembly (C) from unassembled chair and aside momentarily.

2. Slide the 1 piece back assembly (C) into the square tubes the lower frame assembly (B) so that the holes in the back rest line up with the holes located on horizontal brace of the lower frame assembly (B).

3. Raise recliner lock bar (F) adjust position of back assembly (C) until lock release button (G) positively engages middle slot lock bar link when chair is in storage position.

4. Insert screws through holes of the horizontal brace and tighten all screws with screwdriver.

NOTE: Make sure that the top screw on both sides of the coated square tubing from the back assembly are sufficiently secure before using recliner.




Figure 1

OPERATING INSTRUCTIONS:

TO PLACE UNIT IN RECLINING POSITION

BY OCCUPANT:

Place hands on armrests and push against seat back. Legrest will automatically adjust to each recline position.

NOTE: The table can only be used in upright sitting position. Patient should be transported in reclined position with recliner lock set.

BY ATTENDANT:

1. Ensure that recliner lock bar is in stored position. See fig. 1 (I).
2. Stand at either side of recliner.
3. Grasp armrest with one hand, and PVC push bar (J).
4. Push down on push bar to recline the back to the first recline position, to achieve second recline position, push on push bar again.
5. To raise upright, pull forward on push bar.
6. Set recliner Lock Bar (F).

RECLINING LOCK OPERATION

TO LOCK RECLINER:

1. Place recliner into desired position.
2. Pull out Lock-Release Pull Button (G) to release Lock bar (F) from stored position.
3. Rotate recliner Lock Bar (F) down until notches are fully engaged over Locking Pins (H).

TO UNLOCK RECLINER:

1. Lift recliner Lock Bar (F) up to disengage from Locking Pins
2. While holding Lock-Release Pull Button (G) out, rotate recline Lock Bar (F) all the way up until completely against seat back.
3. Release Lock-Release Pull Button (G) to hold recliner Lock Bar in stored position (L).

NOTE: Do not attempt to change position of chair with recliner lock bar engaged. This could cause damage to mechanism.

MAINTENANCE & CLEANING

EVERY THREE MONTHS:

Check and Clean Casters • Tighten Nuts • Check Brakes on Casters • Check and Clean Lock Recline Mechanism

For upholstery maintenance and stain removal, the following hints will be helpful:

Ordinary Dirt: Wash with warm water and a mild soap or detergent.

Stubborn Dirt: Using a soft bristle brush, follow directions above.

Ground-in Dirt: Scrub with powdered cleanser or similar detergent.

Chewing Gum: Scrape carefully; remove with kerosene or naphtha.

Nail Polish and Remover: Blot immediately to prevent damage.

Tars, Asphalt, Creosote: Remove to prevent staining. Clean area with kerosene or naphtha.

Caution: When using kerosene or naphtha, do so in a well ventilated area and keep away from fire and flame.

Paint, Shoe Polish, Heel Marks: Remove immediately! Use a white cloth dampened in kerosene, naphtha or turpentine. Do not use paint remover or liquid brush cleaners.

Ball Point Pen: Blot immediately with a white cloth dampened in water or mineral oil.

Waxing and Refinishing: Improver wearability. Use any quality paste wax,

A diluted solution of 10% (or less) of bleach or clorox may be used when cleaning this chair.



Port Washington, NY 11050

Toll free: 877.224.0946

phone: 516.998.4600

www.drivemedical.com

drive

MEDICAL DESIGN & MANUFACTURING

Port Washington, NY 11050

Toll free: 877.224.0946

phone: 516.998.4600

www.drivemedical.com