EZRIOC+

INSTRUCTIONS



READ
THIS
BEFORE
USING



Read Instruction Manual Completely Before Using EZ Ride





After multiple uses of EZRide+, use multi-tool to tighten all bolts, nuts, and screws on the unit and tow bar.





TABLE OF CONTENTS

Warnings	Page 2
Tow Bar Parts	Page 3
Tow Bar Installation - Chair Clip	Page 4
Tow Bar Installation - Slide Tube	Page 5
Tow Bar Un-Install	Page 6
Tow Bar Hitch Height Adjustment	Page 7
Kickstand Installation	Page 8
Hitch Handle & Kickstand Installation	Page 9
EZ Ride-Wheelchair Connection	Page 10
EZ Ride-Wheelchair Release	Page 11
Speedometer & Handle Controls	Page 12
Handle Fold Instructions	Page 13
Handle Bar Reversal Instructions	Page 14
	Page 15
Adjustable Neck Installation	Page 16
	Page 17
Tow Bar Extension Installation	Page 18
	Page 19
How To Charge	Page 20
Battery Charger Travel Bag	Page 21
EZ Ride Safety Tag	Page 22



Carefully read this manual regarding EZ Ride. EZ Ride is not a toy. Use caution when attached to your wheel chair.

THE MANUFACTURER DISCALIMS ALL LIABILITY RELATING TO DAMAGE CAUSED BY:

- The failure to abide by the instructions in this manual and its instructions.
- EZ Ride being used in ways which is not the intended use.
- EZ Ride being used in ways contrary to applicable laws on safety.
- · Tampering with parts that operate the EZ Ride in an efficient manner.
- · Incorrect assembly.
- Changes made to EZ Ride function and design without permission of the manufacturer.
- Use of non-original parts or parts that are not suitable for the EZ Ride.
- · Repairs not performed by a qualified technician.





for long periods of time, changing attachments, or making adjustments.

Wheel chair clips Release Buttons Release Buttons Slide Tube Release Release Buttons

CHAIR CLIP BREAKDOWN



Chair clip cover

HITCH BREAKDOWN



TOW BAR INSTALLATION

Chair Clip



Place chair clip around horizontal or vertical wheel chair bar. Close to front of chair with screws facing outward.



Place chair clip cover over bar. Confirm it matches the curvature of the bar.



Screw small nut first until it meets the cover, do not tighten. Then place second lock nut on screw. **Do not tighten** completely.




Repeat on other side of chair. Make sure left and right clip are in the same position on the bar. Adjust clips to make as level as possible

TOW BAR INSTALLATION

Slide Tube



Make sure the chair is in the expanded position. The tow bar is spring loaded. Compress the slider tubes and line up with the chair clips.



Squeeze both the top and the bottom release buttons and push the slide tube into the chair clip until the release buttons pop through the chair clip hole. Do on both sides.




Move the tow bar hitch until it is centered between the two foot pads. Then tighten the 2 chair clips making sure the tow bar is level.



Tighten the 2 fastening knobs. It is normal for the tow bar to have some slight movement.


TOW BAR UN-INSTALL



Loosen both fastening knobs.



With one hand squeeze the chair clip release buttons and pull the slide tube toward the center until it releases from the chair clip.



Do the same on the other side. When both are released push both slide tubes to the center of the tow bar then remove from clips and tighten fastening knobs.

TOW BAR HITCH HEIGHT ADJUSTMENT



Normal position for EZ Ride tow bar hitch.



Raise tow bar hitch to raise front wheels of the chair higher off the ground.



Lower tow bar hitch to lower front wheels closer to the ground.



KICKSTAND INSTALLATION



To install kick stand insert kick stand over the plate with the two screws.



Make sure kick stand is straight along back side of EZ Ride.



Install two screw nuts and tighten with wrench.



HITCH HANDLE & KICKSTAND INSTALLATION



Position of the hitch handle assembly is NOT CORRECT.



CORRECT position for hitch handle, aligned even with white lines at top.



If adjustment needed, loosen Allen screws to move hitch handle assembly.



Once hitch handle is positioned, tighten using multi-tool.



Align kickstand screw inserts with white guide lines.




Tighten with multi-tool.


EZRIDE-WHEELCHAIR CONNECTION



While sitting in chair, using steering handle pull EZ ride towards tow bar hitch. Kickstand will automatically close.



Line up EZ Ride handle inside hitch receiver so handle is inserted *under* receiver rod.







Pull EZ ride towards you and once handle is under rod push up to engage tow bar hitch. Once locked in confirm front wheels are off the ground by at least 2-3". If not, adjust Towbar Hitch height. see page 7

EZRIDE-WHEELCHAIR RELEASE



To release EZ ride from Tow Bar push up on steering handle and at the same time lift EZ Ride handle up.



Holding on to EZ ride handle and steering bar Push down and forward to release EZ Ride from Tow Bar Hitch.
Push EZ ride away from Chair to clear footrests.



Pull kickstand away from EZ Ride to the extended position. Insure it is flush to the ground. Make sure EZ Ride is on level ground when extending Kickstand.

SPEEDOMETER & HANDLE CONTROLS



Reverse- R _____ R D

Throttle Controls
Speed 3 mph- this gear is
designed to allow user to cruise
alongside a person walking as
well as indoor use.

Note: Pressing throttle to start ECO speed has 3-second safety delay before starting.

MID Speed 6 mph- this gear is a moderate speed for outdoor use, do not make any sharp turns.

Speed 12 mph- CAUTION.
This gear is fast . Use only
on smooth surfaces in open
conditions. DO NOT MAKE ANY
SHARP TURNS IN THIS SPEED.

How to set cruise control.

1) Hold throttle on desired speed for 5 seconds. This will set the cruise control for that speed.

2) To release cruise control apply brake or push throttle.



Display functions: Speed display, Battery level, Total mileage, Cumulative mileage, currnet speed

Short presses to change speed

Press and hold to power on Note: Some models will not have light function

Press to see mileage/Voltage/ Trip.When trip is showing press M button two times to record mileage





HANDLE FOLD INSTRUCTIONS




To fold handle to down position grab round release ring and pull towards handle grip.





Once release ring extended push handle to down position






To adjust angle of Brake or Speedometer turn Allen screw counter clockwise to loosen. Adjust to position desired and tighten Allen screw

HANDLE BAR REVERSAL INSTRUCTIONS

First, take off the front bracket by removing the four 4mm hex screws and rest the handle bars beside EZ-Ride.







Then loosen the two screws that clamp the handle bar stem to the steering column using a 5mm hex key. Only loosen the stem until it is able to rotate.



HANDLE BAR REVERSAL INSTRUCTIONS

Rotate the stem 180 degrees and looking down from the top of the EZ-Ride and line up the stem with the drive wheel. Once both are lined up properly, tighten the stem down switching between the two screws so they are both tightened down evenly.





Place the handle bars back on along with the bracket and start by hand tightening the four screws to get the threads started. Then tighten the screws in a pattern using the multitool so all screws will be tightened down evenly.






ADJUSTABLE NECK INSTALLATION

First, take off the front bracket by removing the four
 4mm hex screws and rest the handle bars beside the EZRide.



2. Then loosen the two screws that clamp the handle bar stem to the steering column using a 5mm hex key, until the standard EZRide handle bar neck can be removed.






3. Place the new adjustable neck on the steering column as shown at right and tighten until it's securely in place.



ADJUSTABLE NECK INSTALLATION

4. Attach the handle bars to the adjustable neck by removing the four (4) hex screws and placing the handle bars as shown, and tighten until the handle bars are secure.







TOW BAR EXTENSION INSTALLATION

1. Use the included multitool and a wrench to loosen, and remove the 3 screws attaching the hitch to the tow bar.




2. Slide the hitch off the tow bar.



3. Slide the tow bar extension accessory onto the tow bar. Determine how far you want the EZRide to sit from the wheelchair - 3 or 6 inches.



4. Align the screw holes to the desired extension.




TOW BAR EXTENSION INSTALLATION


5. Insert the 3 screws. Fingertighten the nuts. Then, using the multi-tool and a wrench, tighten the screws to secure.



6. Slide the hitch on to the end of the tow bar extension, insert the centermost screw and finger-tighten.



7. Adjust the angle by tilting the hitch until the proper screw holes match. Then insert the remaining 2 screws. Tighten and secure all 3 screws.



8. This final installation image shows the tow bar extension set for 6 inch distance.



HOW TO CHARGE







Insert three prong charging cable into port on top of EZ Ride.

Plug into normal 110 outlet.

Keep plugged in until light on charger turns green. Best to charge after each use.

Note: Like a car EZ Ride will lose charge over time if not used on a regular basis . Check battery before using EZ Ride

BATTERY CHARGER TRAVEL BAG





Battery charger bag can be used for back of wheelchair mounting or clips can be joined together for hanging or shoulder use.









READ THIS BEFORE USING

Read Instruction Manual Completely Before Using EZ Ride

- DO NOT use medium or high speed indoors. Use eco speed only.
- DO NOT make a 360 degree turn using medium or high speed.



DO NOT use EZ Ride on an incline of more than 30 degrees.



- DO NOT use high speed until you are comfortable with eco & medium speed.
- DO NOT use EZ Ride in sand or loose gravel.

