

Flexible Switch

Flexible Switches are adhesive-backed, pressure activated switches. These switches are flexible which allows them to be attached to various objects and surfaces, essentially turning those objects into the switch itself.

- The minimum bending radius of the Flexible Switch is 1.5”.
- The Flexible Switch cannot be trimmed or cut in any way.
- The Flexible Switch is not designed to be used with adapted toys.

Before peeling the brown backing off and adhering, first trial fit the Flexible Switch and plug it into the corresponding assistive device to check for correct operation. The Flexible Switch uses a very aggressive adhesive. Keep this in mind when attaching the Flexible Switch, because in most cases, it will be a permanent placement. If you wish to frequently peel up and reapply the Flexible Switch, you may consider the following:

- Peel off the backing and adhere the Flexible Switch to a transparency sheet.
- Use small pieces of Velcro in each corner to adhere to surfaces.
- Use Adaptivation’s Reusable Adhesive to keep reapplying Flexible Switches in a less permanent manner.

To give more meaning to your Flexible Switch, photos or symbols may be attached directly on the surface. Activation can then be done by simply touching the photo or symbol directly.

Flexible Switch

Flexible Switches are adhesive-backed, pressure activated switches. These switches are flexible which allows them to be attached to various objects and surfaces, essentially turning those objects into the switch itself.

- The minimum bending radius of the Flexible Switch is 1.5”.
- The Flexible Switch cannot be trimmed or cut in any way.
- The Flexible Switch is not designed to be used with adapted toys.

Before peeling the brown backing off and adhering, first trial fit the Flexible Switch and plug it into the corresponding assistive device to check for correct operation. The Flexible Switch uses a very aggressive adhesive. Keep this in mind when attaching the Flexible Switch, because in most cases, it will be a permanent placement. If you wish to frequently peel up and reapply the Flexible Switch, you may consider the following:

- Peel off the backing and adhere the Flexible Switch to a transparency sheet.
- Use small pieces of Velcro in each corner to adhere to surfaces.
- Use Adaptivation’s Reusable Adhesive to keep reapplying Flexible Switches in a less permanent manner.

To give more meaning to your Flexible Switch, photos or symbols may be attached directly on the surface. Activation can then be done by simply touching the photo or symbol directly.