# NS-Square Instruction for Use





# Contents

Heading	Page
General/Symbols/Intended use/Intended enviroment	4
Practical handling	5
Notice/Materials/Cleaning	6
Articles	7
Service Information	8

### General

Thank you for choosing an Etac product.

To avoid accidents and injury when moving and handling the products, read the manual carefully.

The person described as "the user" in this user manual is the person who is lying or sitting on the product. The assistant or assistants are the people who manoeuvre the product.



This symbol appears alongside the text in the manual. It draws the reader's attention to points at which there may be a risk to the health and safety of the user or assistant.

The products comply with the standards applicable for Class 1 products in the European Council Directive MDD 93/42/EEC on medical devices.

### Lot no/Batch no:

x	x	x	х	x	х	х	х	х	х
Production year		Running number							


At Etac we strive to improve our products all the time and therefore we reserve the right to make changes to products without prior warning. All measurements given on illustrations and similar material are for guidance only and Etac cannot be held liable for errors and defects.

The information given in this manual, including recommendations, combinations and sizing, does not apply to special orders and modifications. If the customer makes adjustments, repairs or combinations not predetermined by Etac, the Etac CE certification and Etac warranty will be voided. If in doubt, please contact Etac.

Warranty: Two-year warranty on material and manufacturing defects, provided that the product is used correctly.

For further information on the Etac transfer range, see www.etac.com.

The product can be scrapped in accordance with national regulations.



### Intended use

The NS-Square can be used to increase friction under the feet, rear, shoulder blades - anywhere where increased friction is desired.

## Intended enviroment

# Practical handling

### Positioning

The NS-Square can be positioned where it is best for the individual user.

Use

The NS-Square provides the user with extra friction when moving/turning, etc.

# Notice

### Special features

Always check the product before use and after washing.

Never use a defective product. If the product shows signs of wear-and-tear, it must be scrapped.


Read these instructions carefully.

It is important that assistants receive instruction in manual handling. Etac offers advice and training for assistants. For further information, contact Etac.

Always use the correct manual handling techniques.

Encourage the client to assist where possible.

To ensure that the client feels safe and that every manual handling is smooth, always plan the manual handling in advance.





Never leave the product on the floor.



Always make a risk assessment, and secure that the assistive product can be used at the individual user and in combination with other devices that it is safe for the user and caregivers.

If in any doubt - please contact Etac.

### Materials

Plastazote LD-45

# Cleaning

The product should be checked regularly, preferably each time it is used, and especially after wash.

Check that there is no damage to seams or fabric.



Never try to repair a product yourself. Never use a defective product. Washing instructions: Do not use fabric softener.



# Articles

Article no.	Description	Size (mm)
IM2248	NS-Square	B380 x H5 x L480

# Service Information

Thank you for choosing an Etac product. If the customer makes adjustments, repairs or combinations not predetermined by Etac, the Etac CE certification and Etac warranty will be voided.

**Warranty:** Two-year warranty on material and manufacturing defects, provided that the product is used correctly. Before taking a product in service always make a risk assessment according to national and/or local legislation.

### First inspection:

- Is the packaging intact?
- Read the label on the packaging and check the article no. and product description
- Check that Short Instruction is enclosed updated User Manual/Instruction for use can be downloaded from www.etac.com or contact your Etac Customer Service or the local distributor.
- Check the label on the product does it include article no., product description, lot/batch no., cleaning instructions and supplier name?

#### **Periodic Inspection:**

- Make sure that your Manual transfer system always is in a perfect condition.
- After wash always check materials, stitching, handles, buckles.
- If the product shows signs of wear and tear, it must be removed from service immediately.
  - Lot no/Batch no: x x x x x x x x x x x x x x Production year Running number



### Visual inspection/Check the product:

Ensure that the materials, seams, stitching, handles, buckles are intact/faultless.



**Stability test:** Try to bend the product verify that it feels firm, stable and solid.



**Mechanical load or stress/Test handles:** Draw hard in the handles in opposite directions and control the material, seams and stitching. Test buckles:


Lock the buckle and draw in opposite directions, control the buckle and the stitching.



#### Test low/high friction:

Place the product on a firm surface or a bed, place your hands on the material and test the friction by pushing your hands down into the product. Low friction – slides effortlessly High friction – no sliding/moving

Check always:



If in doubt, please contact Etac Customer Service or local distributor for more information and guidance. For more information about training and the use of these products, contact the Etac transfer experts – www.etac.com.

Class 1 - European Council Directive MDD 93/42/EEC on medical devices

8

#### Manufacture:

Etac Immedia A/S Egeskowej 12 DK-8700 Horsens, Denmark etac.immedia@etac.com

#### Export:

Etac Immedia A/S Egeskovvej 12 DK-8700 Horsens etac.immedia@etac.com www.etac.com/exp

Etac Sverige AB Box 203, 334 24 Anderstorp, S Tel +46 371-58 73 00 Fax +46 371-58 73 90 info@etac.se www.etac.se

Etac AS Pb 249, 1501 Moss, N Tel +47 815 69 469 Fax +47 69 27 09 11 hovedkontor@etac.no www.etac.no

Etac A/S Egeskowej 12, 8700 Horsens, DK Tel +45 79 68 58 33 Fax +45 75 68 58 40 info@etac.dk www.etac.dk

Etac GMBH Bahnhofstraße 131, 45770 Marl, D Tel +49 236 598 710 Fax +49 236 598 6115 info@etac.de www.etac.de

Etac Holland BV Fluorietweg 16a, 1812RR Alkmaar, NL Tel +31 72 547 04 39 Fax +31 72 547 13 05 info.holland@etac.com www.etac.com

R82 UK Ltd. Unit D4A, Coombswood Business Park, East Coombswood Way, Halesowen,West Midlands B62 8BH, UK Tel 0121 561 2222 Fax 0121 559 5437 R82uk@r82.com www.r82.co.uk

Snug Seat Inc. 12801 E. Independence Blvd., P.O. Box 1739, Matthews, NC 28106, US Tel 1 800 336 7684 Fax 704 882 0751 information@snugseat.com www.snugseat.com

