

Shift Mode

To Enter
Slide the left dome to green zone twice

To Exit
Slide the left dome to green zone twice

Cap Lock Mode

To Enter
Slide the left dome to grey zone twice (Cap LED will illuminate)

To Exit
Slide the left dome to grey zone twice

Mouse Mode

To Enter
Slide the left dome to black zone twice (Mouse LED will illuminate)

To Exit
Slide the left dome to black zone twice



Num Lock Mode

To Enter
Slide and hold left dome in grey zone (Num LED will illuminate)

To Exit
Slide and hold left dome in grey zone

A	B	C	D	E	F	G	H	I	J	K	L	M
N	O	P	Q	R	S	T	U	V	W	X	Y	Z
~ `	! 1	@ 2	# 3	\$ 4	% 5	^ 6	& 7	* 8	(9) 0	_ -	+ =
{ [}]	< ,	> .	? /	: ;	" '	\	Space	Backspace	Return	Tab	
Windows	Control	Alt	Delete	esc	Enter	Print Screen	Scroll Lock	Pause	Page Up	Page Down		

F1 F2	F3 F4	F5 F6
F7 F8	F9 F10	F11 F12
Insert	Home	End
	↑	
←	↓	→

Num Lock	/	*	-
7	8	9	+
4	5	6	
1	2	3	Enter
0	.		

