

# Electrical Operated Stand Up Desk Assembly Guide for 60" & 48" Wide Flat Top Desks

### **Table of Contents**

Table of Contents	3
Warnings & Guidelines	4
Parts List & Hardware	5
Assembly and Installation	
Assemble the right and left frame	6
Assemble the cross bars	7
Attach electric adjustment housing	8
Flip desk upright and install optional electric	9
Install rotating cross bar	10
Mount power supply to unit	11
Plug in electrical cords to power supply	12
Attach the desk surface	13
Attach remaining bolts to the desk surface	14
Mount electrical controller and cable clips	15

### **Tools Recommended**

- Phillips Screwdriver

### **ATTENTION!**

Do not fully tighten screws until completely assembled

### **WE ARE GIVING YOU A STANDING OVATION**

You did it! You took the first step towards healthier living by purchasing our stand up desk. We couldn't be happier to have you joining the millions of people who were tired of sitting around and ready to take a stand for a healthier life.

This desk was built with you in mind and every detail was carefully crafted. The following assembly guide is best accomplished with two people. If you have any questions or concerns contact your local dealer

# IMPORTANT SAFETY INSTRUCTIONS

# Read all instructions before using the product.

Every person who is responsible for this table at installation or employment of the table in daily use or in service and repair work should carefully read these instructions. Keep these instructions close to your sit/stand table.

#### DANGER

To reduce the risk of electric shock: Always unplug this furnishing from the electrical outlet before cleaning.

#### WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. Unplug from outlet before putting on or taking off parts.
- Use this furnishing only for its intended use as described in these instructions. DO NOT use attachments not recommended by the manufacturer.
- DO NOT operate this furnishing
  if it has a damaged cord or plug,
  if it is not working properly, if it
  has been dropped or damaged,
  or dropped into water. Return the
  furnishing to a service center for
  examination and repair.
- Keep the cord away from heated surfaces.
- DO NOT use outdoors.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.

- DO NOT overload the table maximum load is 70kg / 154 lbs.
- 8. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.

This appliance shall only be used together with the included power supply unit. If you are having trouble with your power supply or your power supply is not operating correctly, **DO NOT** disassemble contact your local dealer.

#### **Usage of the Table**

- The table shall only be used as a working table with the possibility to continuously adjust working height between sitting and standing position. The table shall only be used indoors and in dry premises (office environment or similar).
- The table must not be overloaded

   maximum load is 70 kg / 154
   lbs. The motors may be run continuously for a maximum of one (1) minute. Afterward, the motors must stand by for approximately nine (9) minutes before they can be used again.
- The motors stop automatically when the table reaches its lowest or highest position respectively.
- If the unit has been unplugged or a power outage occurs a system reset will need to be performed.
   To reset the system simply hold the right (lowering) button until the desk reaches it's lowest position then wait for (5) seconds for the gears to reset.
- ATTENTION! The electrical cable must have full mobility. Place the cables so that they DO NOT get tangled or damaged.
   3 / 16

#### **Adjusting Table Height:**

- Make sure no objects will obstruct the table when adjusting table height.
- In order to run the table up/down, press the controller buttons with an arrows pointing up and down respectively.
- 3. Unplug the hand controller when not in use to prevent unauthorized use.

#### **Safety Regulations:**

- When the table is run up/down, keep a safe distance to avoid the risk of being squeezed between the moving table top and fixed objects in the surrounding area.
- When the table is run up/down the user shall keep watch so that nobody is injured or no object is damaged. The table top must not bump into a fixed object so that the table is overturned. Always remove any office chair before the table is run up/down.
- When the table is left unattended, the hand control plug must be unplugged and placed out of reach of children.
- The table tripod must not be altered or reconstructed in any way. In service and repair work of the table, the electrical cable must always be disconnected from the wall socket.
- Alterations to the control box are absolutely forbidden!
- The table must not be used as a hoisting device for persons.

#### **Maintenance and Repair:**

 After approximately one (1) week of use, check that the screws are properly tightened.

- If the table cannot be lowered or raised, check the connections between the legs and the wall socket and be sure the plugs are inserted fully into the power supply.
- If any part of the electrical system should need to be replaced, disconnect the electrical cable from the wall socket before replacing the electrical part to avoid risk of injury. After the electrical part has been replaced, connect the electrical cable back to the wall socket. The table is now ready for use.
- If the table still does not work please contact your local dealer.

#### SAVE THESE INSTRUCTIONS


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.


#### WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. For more information please contact your dealer.




### Assemble the right and left frame



**Gather Parts:** 

A, B, J, K, R, 9







**4** ×4 M6x48

7/16

# Attach electric adjustment housing




# 4 Flip desk upright and install optional electric




**IMPORTANT:** Install the **OPTIONAL** electric (**SOLD SEPARATELY**) before attaching the desk top to the frame.

# 5 Install rotating cross bar



**Gather Parts:** N, E

# 6 Mount power supply to unit




**Gather Parts:** G, H


### Plug in electrical cords to power supply


Attach the cable that is connected to the motor to the center plug. Make sure the pins line up correctly.






 $(\mathbf{2})$ 







Attach the cable that is connected to the controller to the left plug. Make sure the pins line up correctly.




To set up the system, hold the right button untill the unit is at its lowest position then wait for five (5) seconds. Also do this when a power outage occurs or if the unit has been unplugged.


## 8 Attach the desk surface






### Attach remaining bolts to the desk surface





### Mount electrical controller and cable clips



Revision Date: 09/09/2015

**Questions or Feedback Call Us at:** 

800-323-4656